


# CAMON

## LAWN SCARIFIER

### OPERATING INSTRUCTIONS & SAFETY NOTES

### IMPORTANT PLEASE READ CAREFULLY

No liability will be accepted for any damage caused to persons or property through failure to observe the operating and safety instructions.



### OPERATING HINTS

The machine must NOT be used as a slitter or aerator as the blades will damage the lawn, and the machine will be damaged.

Always use the machine at maximum engine speed.

Empty the grassbag frequently.

If the Scarifier should strike a stone or similar object, STOP the engine immediately and wait for the blades to stop rotating. Inspect the Scarifier for damage and if in any doubt contact your supplier.

### TO STOP THE ENGINE


Release the operating lever.

Switch the ignition to 'OFF' position.

Turn the fuel tap to 'OFF' position.

Wait for the blades to stop rotating before attempting to move the machine.

**WARNING: THE EXHAUST COVER  
MAY BE HOT - DO NOT TOUCH.**



Noise emissions - 86.9dB(A) (pressure)  
- 103.5dB(A) (pressure)  
- 98.9dB(A) (pressure)

Ear defenders to be worn to BS EN352-1: 1993

Vibrations transmitted - 6.25m/sec sq

**020 8351 3434**

**SCAN ME** TO DOWNLOAD THE MPH APP  
EQUIPMENT INVENTORY | SPECIFICATIONS  
TUTORIALS | TRAINING | SUPPORT

Head office: 120 Hertford Road, Enfield EN3 5AX  
e: [info@mrplanthire.co.uk](mailto:info@mrplanthire.co.uk) | w: [mrplanthire.co.uk](http://mrplanthire.co.uk)